GRAM S2

DESIGNED IN EUROPE

CE · M² INTERN · 220 V · BAT.INT · RS-232 · PRINT.EXT · USB · CAL.EXT · MOVE · TOL · INOX · ABS · LCD DISPLAY

Advanced multiuse scales

- **Very clear viewing, with large-size display.**
- **Identifies whether the weight is within a range of values.**
- **Accumulates and prints any weighings made (with optional printer).**
- **Configures header and footer lines of the ticket printout (with optional printer).**
- **Prints labels with Q2 labelling machine (optional).**

Functions:

- **Auto-hold:** Retains the weight value on screen even after removing the object.
- **Tare:** Normal, fixed and automatic.
- **Data:** Sends data directly to PC (with optional USB Direct cable).
- **Information:** Indicates date and time on ticket or label.

Model	S2-800	S2-1500	S2-8K	S2-15K
Reference	71097	71095	71098	71096
Capacity (g)	800	1.500	8.000	15.000
Resolution (g)	0,1	0,1	0,5	1
Power	230V / 50 Hz (Euro) – 7,5V			
Working temperature	+-5°C /+35°C			
Battery duration	15 – 48 hours, depending on use			
Visor	Backlit LCD			
Segments	6 digits			
Digit height (mm)	25			
Weighing units	g			
Material of the structure	ABS			
Connectivity	Two-way RS-232C			
Sealing protection	IP-52			
Dim. of weighing plate (mm)	280 x 193			
Product dim. (mm)	307 x 280 x 114			
Product net weight (kg)	3,1			
Packaging dim. (mm)	370 x 320 x 160			
Total weight with packaging (kg)	3,9			
RRP (€)				

Ref.	Options	RRP (€)
8023	**ISOCAL certificate from 0.01 g to 30 kg**	45,00

Ref.	Accessories	RRP (€)
5263	**RD3 repeater indicator (RS-232)**	140.00
70814	**Q2 label printer**	190.00
70034	**PR4 printer (RS-232)**	150.00
3792	**EX-Link software for PC**	Free of charge
4877	**PW-Link software for PC**	140.00
36787	**Direct S USB cable**	48.00
36788	**RS-232 cable to RD3 or PC S, 1.5 m**	44.00
3739	**RS-232 cable to RD3 or PC S, 4 m**	56.00

Easy reading
Its large-size display facilitates reading.

Q2

PR4

Printing of results
Q2: Prints ticket and pre-cut label (56mm x 70mm).
PR4: Prints ticket.

Data export
USB Direct: With our direct cable between your S2 scales and your PC, the weighing data will appear in any application or document you have open. No software or installation.

EX-Link: Excel-based software that allows you to view the weight value on your PC and memorize it in cells (Microsoft Excel software not included). You need an RS232C connection cable to PC.

PW-Link: This communication software allows you to send reading data to a spreadsheet or text editor on your PC.

External dimensions (mm)

S2

114
307
280

More information

http://gram-group.com/producto/gram-s2/

GRAM